



# DuraCoat® Super-Saver Refills for Gerber Edge® Printers

## INSTRUCTIONS


1. Position cartridge as shown. Open cartridge by removing 4 endcaps. Pry off endcaps as shown. (NOTE: endcap tabs will break)




2. Remove used Ribbon and place Gears and Hubs into the Cores of the new Super-Saver Refill.



3. Place Super-Saver Refill into cartridge as shown.



4. Close cartridge covers and secure with supplied endcaps.



5. Adhere extra label from Super-Saver Refill package to cartridge to indicate Color.

